




# QUICK START


## NON-CONTACT VOLTAGE DETECTORS + FLASHLIGHT

### MODELS VP40 and VP42



## Introduction

The VP40\_VP42 detects the presence of AC voltage at electrical outlets, junction strips, electrical circuits, and other devices without having to physically contact the device. The VP40 has a minimum excitation voltage of 90V AC; The VP42 has a minimum excitation voltage of 190V AC. Both models have a high sensitivity mode allowing detection down to 24V AC. Vibrating and visual cues alert the user when AC voltage is present. Bright tip lights permit operation in dimly lit areas.



- |                      |                      |
|----------------------|----------------------|
| 1. AC voltage sensor | 6. Pocket clip       |
| 2. Tip lights        | 7. Flashlight button |
| 3. Alarm indicator   | 8. Battery           |
| 4. Status indicator  | compartment cap      |
| 5. Power button      | 9. Flashlight        |

## Quick Steps

### WARNINGS

Test a known live circuit before testing an uncertain circuit. Varying electrical socket designs and insulation thickness and types can affect the meter's voltage detection performance; please use caution

1. Short press power button (5) to switch ON
2. Tip lights (2) will be ON and the status indicator (4) will glow solid green
  - If status indicator flashes amber, replace batteries
  - If status indicator flashes red, return unit for service
3. Short press power button to toggle low/high sensitivity (solid green status indicator for low sensitivity and solid amber for high sensitivity)

4. Hold the sensor tip (1) close to a voltage source. The meter's detection distance is 1 cm (0.4") max.
5. If voltage is present, the device vibrates and the alarm indicator (3) flashes red (low sensitivity mode) or amber (high sensitivity mode)
6. Long press Flashlight button (7) to switch the light ON/OFF (Flashlight and detector will not function at the same time)
7. The device has an APO (auto power off) of 3 minutes. The Flashlight APO is 30 minutes
8. Long press the power button to switch OFF
9. Refer to detailed user manual, available at <http://support.flir.com> for more information

## ***Cleaning***


---

With the meter OFF, wipe the housing with a damp cloth as needed, do not use harsh detergents, abrasives, or solvents. Use compressed air to clear dust particles from the Flashlight lens. Clean the lens with a commercial lens cleaner when necessary. Ensure that the device is dry before performing tests.

## ***Battery Replacement***

---

- With the meter OFF, unscrew the battery compartment cap (8) and remove the batteries.
- Insert two new 'AAA' batteries in the proper orientation.
- Secure the compartment cover ensuring that the red plastic ring in the battery cap aligns with the battery, as shown.
- Check that the device powers up correctly before use.





Recycle used batteries, do not dispose in household trash. Follow all regulations with respect to the disposing of this device at the end of its lifecycle.

## ***Three-Year Limited Warranty***

---

This product is protected by FLIR's 3-Year Limited Warranty. Visit [www.flir.com/testwarranty](http://www.flir.com/testwarranty) to read the 3-Year Limited Warranty document. Register your product at the website to receive a free 1-year warranty extension.

## ***On-line User Manual***

---

The detailed User Manual is located on the <http://support.flir.com> web site (*download* tab). Please read the entire user manual before use.

## ***Specifications***

---

VP40 Range	90 ~ 1000V AC (normal mode) 24 ~ 1000V AC (high sensitivity mode)
VP42 Range	190 ~ 1000V AC (normal mode) 24 ~ 1000V AC (high sensitivity mode)
Frequency	45 ~ 65Hz
Overvoltage	CAT IV 1000V AC
Detection distance	0 ~ 0.4 in. (0 ~ 1 cm)
Operating temp.	-32 ~ 140°F (0 ~ 60°C)
Storage temp.	-40 ~ 194°F (-40 ~ 90°C)
Safety compliance	CE, UL/cUL, RCM
Drop Test	9.8 ft. (3m)
Battery	2 x 'AAA'
Battery life	7 hours continuous (Flashlight off)
APO	Meter: After 3 minutes of inactivity Flashlight: After 30 minutes
Dimensions	1.1 x 1.0 x 6.1 in. (29 x 26 x 156 mm)
Weight	0.44 lbs. (0.20 kg.); with batteries



---

## Corporate Headquarters

FLIR Systems, Inc.

2770 SW Parkway Avenue

Wilsonville, OR 97070 USA

Telephone: +1 503-498-3547

## Customer Support

Technical Support Website

<http://support.flir.com>

Technical Support Email

[TMSupport@flir.com](mailto:TMSupport@flir.com)

Service and Repair Email

[Repair@flir.com](mailto:Repair@flir.com)

Support Telephone +1 855-499-3662 option 3 (toll free)

Publication Identification No.: VP40\_VP42-QS

Release version: AA

Release Date: August 2018

Language: en-US

**Copyright © 2018 FLIR Systems, Inc.**

All rights reserved including the right of reproduction in whole or in part in any form.

**[www.flir.com](http://www.flir.com)**