



S4 rechargeable QUICK GUIDE


This manual may contain typographical errors.
Data and information are subject to
change without notice




FOR MORE INFO

Steiner A/S
Dyssevej 3
DK-8200 Århus N
Phone: +45 87 52 52 12
Fax: +45 87 52 52 15
Contact: info@suprabeam.com
www.suprabeam.com


Head angle



Changing and charging battery



Helmet mount



*Helmet mount is sold separately

Additional online information

Warning



Eye Safety

Risk Group 2
(IEC 62471)




Specifications



Li-Po



85 m



IP 68



145 g

Light Control Functions

TOP BUTTON



CLICK




ON = MEDIUM/LAST USED LEVEL

CLICK



PUSH



> 0.5 SEC




OFF

BOTTOM BUTTON



CLICK



BOTH BUTTONS




PRESS AND RELEASE

BATTERY LEVEL




0.3 SEC - 3 SEC



TRANSPORTATION
LOCK



3 SEC - 9 SEC



ECO/POWER MODE



> 9 SEC



ECO MODE (STANDARD)

POWER MODE

